

Comment mesurer les fenêtres standards

How to measure standard windows

Installation à l'intérieur (ID)

Largeur : Mesurez la distance (A) entre les surfaces intérieures du cadre de la fenêtre en haut, au milieu et en bas, et utilisez la largeur la plus étroite.
Hauteur : Mesurez la distance (B) de la surface intérieure au haut de la fenêtre jusqu'au rebord de la fenêtre.

Si la fenêtre n'a pas de rebord, mesurez la hauteur jusqu'à l'endroit où le store doit s'arrêter

Installation à l'extérieur (OD)

Largeur : Mesurez la distance (C) entre les endroits où le store doit s'arrêter. Pour un contrôle optimal de la lumière, cette mesure devrait dépasser l'ouverture de fenêtre de 1,5 po de chaque côté (ou 3 po pour la largeur entière).
Hauteur : Mesurez la distance (D) de l'endroit où le store doit être placé en haut jusqu'au rebord de la fenêtre. Si la fenêtre n'a pas de rebord ou si le store doit chevaucher le cadre de la fenêtre, mesurez jusqu'à l'endroit où le store doit s'arrêter.

E : Seulement pour les corniches Europa installée à l'intérieur. SVP déduire 0,25 po sur la hauteur du store pour le couvre poussière.

Inside Mount (ID)

Inside: Mounted blinds emphasize the size of the window and allows mouldings and trims to be visible. Be sure the window's inside depth clearance is enough to install the mounting bracket (2")

Width: Measure the distance (A) between the inside surfaces of the window frame at the top, middle and bottom, and use the narrowest measurement.

Height: Measure the distance (B) from the inside surface at the top of the window to the sill.



Outside Mount (OD)

Outside Mounted blinds enable the headrail to be mounted above the window or on the moulding. Outside Mounts can create illusions such as to make a narrow window appear larger. Outside Mounted blinds may be necessary if the window is not deep enough to install the mounting brackets (2")

Blind Width: Measure (C) to the outside width of the window frame. Add at least 3 inches for overlap (1.5" per side).

Blind Height: Measure from the sill to the position of the top of the shade (D). If there is no sill, measure to where the blind should reach.

E : Only for Europa cornice inside mounted blinds. Please deduct 0.25" from the height of the blind to allow for the dust cover.



F : Hauteurs d'entassement des stores horizontaux
Horizontal Blinds Stacking Heights

Hauteur du store Blind Height	Hauteur d'entassement Stack Height
36"	6"
48"	7"
60"	8"
72"	9.5"
84"	11"
120"	14"